

QUICKSTART CHECKLIST

NOTE: For first time users, we recommend you download and read the SpeedLight User Manual from our online knowledge base for a more detailed explanation of the system.

Visit support.swiftperformance.com and search for 'User Guides – Manuals'.

- Ensure all devices are powered off
- Turn Wi-Fi Access Point on
- In iPad Settings > Wi-Fi wait for SpeedLAN_X
- When visible connect to SpeedLAN_X
 - If asked, the password is 'speedlight'
- Turn on SpeedLink (Wait for one minute)
- Open SpeedLight App on your iPad
- Go to 'Setup & Connection' page
 - If you get a 'No IP' error start again
- Select a test & turn other SpeedLight devices on
 - Drag and drop devices in appropriate locations in app
- Go to 'Run Test' page
- Arm System

Release: 25/10/2017

HAVING PROBLEMS?

1. Ensure your SpeedLink is placed in an elevated position
i.e. put the SpeedLink on top of the SpeedLight carry case, a table, etc.
NEVER PUT THE SPEEDLINK ON THE GROUND
2. Keep the Wi-Fi Access Point at least 40cm (16") away
from the SpeedLink and iPad
3. Make sure all antennas are pointing upwards
This includes Gates, SpeedLinks, SpeedStarts, and SpeedReaders.
4. Are your antenna connectors loose?
A loose antenna fitting can result in internal damage that will limit the
range of your devices significantly and causes slowing of system response.

Visit support.swiftperformance.com for online help